

# ProFormX™

## WINDSHIELD

### INSTALLATION INSTRUCTIONS

Fits E-Z-GO® RXV®

PART# 80-202



Strut Brackets

## PARTS LIST

- Windshield
- Strut Brackets

## STEP 1

Remove protective plastic from all four sides of windshield.

Install the strut brackets as shown onto the sides of the windshield.

Repeat on other side.



## STEP 2

Once the strut brackets have been installed on the windshield, attach windshield on front struts of cart as shown.

Slide the windshield down to the cowl.



## STEP 3

Once the base of the windshield is attached, raise the top half and clamp as shown.



Club Car®, Precedent®, and DS® are registered trademarks of Ingersoll Rand, Inc. E-Z-GO®, TXT®, and RXV® are registered trademarks of Textron Innovations, Inc. ("Textron"). Yamaha®, G-14®, G-19®, G-22® G-29®, and Drive2® are registered trademarks of Yamaha Golf-Car Company and Yamaha Motor Corporation ("Yamaha"). Reference to Club Car®, E-Z-GO®, or Yamaha® or their associated trademarks and products is only for purposes of identifying golf carts with which this ProFormX™ product is compatible. ProFormX™ products are aftermarket parts and are not original equipment parts. ProFormX™ is not connected or affiliated with or sponsored by Club Car®, E-Z-GO®, or Yamaha® or endorsed by Ingersoll Rand Inc®, Textron Innovation Inc®, or Yamaha Golf Cart Company®.

**MYPROFORMX.COM**