

ProFormX™ WINDSHIELD

INSTALLATION INSTRUCTIONS

Fits E-Z-GO® TXT® and E-Z-GO® Freedom TXT®

TXT PART# 80-200

FREEDOM PART# 80-201



Strut Brackets



Hardware

TOOLS NEEDED

- 10mm Wrench
- 10mm Socket

PARTS LIST

- Windshield
- Strut Brackets
- Hardware

STEP 1

Remove protective plastic from all four sides of windshield.

Attach strut bracket to windshield as shown.

Repeat process on other side.



STEP 2

Using rubber grommet provided, insert hardware.

Repeat this process on other side.



STEP 3

Firmly push windshield strut bracket to the front struts on both sides.



STEP 4

Using provided hardware, mount windshield to the front struts using 10mm wrench and socket.



STEP 5

Tighten hardware on both sides.



Club Car®, Precedent®, and DS® are registered trademarks of Ingersoll Rand, Inc. E-Z-GO®, TXT®, and RXV® are registered trademarks of Textron Innovations, Inc. ("Textron"). Yamaha®, G-14®, G-19®, G-22® G-29®, and Drive2® are registered trademarks of Yamaha Golf-Car Company and Yamaha Motor Corporation ("Yamaha"). Reference to Club Car®, E-Z-GO®, or Yamaha® or their associated trademarks and products is only for purposes of identifying golf carts with which this ProFormX™ product is compatible. ProFormX™ products are aftermarket parts and are not original equipment parts. ProFormX™ is not connected or affiliated with or sponsored by Club Car®, E-Z-GO®, or Yamaha® or endorsed by Ingersoll Rand Inc®, Textron Innovation Inc®, or Yamaha Golf Cart Company®.